

BMW Motorrad

Maintenance schedule

0145 - G 450 X, K16



| | | | |
|----------------------|----------------------|----------------------------------|----------------------|
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| Customer | Registration No. | Odometer reading | Operating hours |
| <input type="text"/> | <input type="text"/> | <input type="text"/> | |
| Order No. | Date | Mechanic's + Manager's signature | |

00 00 111 BMW Service

| | | |
|--|---|--------------------------|
| Reading fault memory with BMW Motorrad diagnostic system | | <input type="checkbox"/> |
| 11 00 611 Oil change, engine, with filter | Every 10 operating hours | <input type="checkbox"/> |
| 13 72 532 Renewing air cleaner insert | Every 10 operating hours | <input type="checkbox"/> |
| 11 34 502 Checking valve clearance (for maintenance) | Initially after 10 operating hours, then every 20 operating hours | <input type="checkbox"/> |
| 11 00 646 Checking pressure loss with BMW diagnostic unit (spark plug removed) | Initially after 10 operating hours, then every 20 operating hours | <input type="checkbox"/> |
| Checking spark plug | | <input type="checkbox"/> |
| Checking clean-side chamber of the intake air silencer for leaks | | <input type="checkbox"/> |
| Checking clutch cable and clutch-lever play | | <input type="checkbox"/> |
| Checking fuel system | | <input type="checkbox"/> |
| 11 00 647 Engine service | Every 70 operating hours | <input type="checkbox"/> |
| Checking cylinder head (as part of engine service) | | <input type="checkbox"/> |
| Replacing exhaust valves (as part of engine service) | | <input type="checkbox"/> |
| Replacing spark plug (as part of engine service) | | <input type="checkbox"/> |
| Replacing piston (as part of engine service) | | <input type="checkbox"/> |
| Replacing crankshaft (as part of engine service) | | <input type="checkbox"/> |
| Checking slip coupling in primary drive (as part of engine service) | | <input type="checkbox"/> |
| Checking gearbox (as part of engine service) | | <input type="checkbox"/> |
| Checking and cleaning swinging-arm axle (as part of engine service) | | <input type="checkbox"/> |
| Checking condition of exhaust system | | <input type="checkbox"/> |
| Check the security of the threaded fasteners for frame, side stand and trim panels | | <input type="checkbox"/> |
| Checking cooling system | | <input type="checkbox"/> |
| Checking front brake pads and brake disc for wear | | <input type="checkbox"/> |
| Checking rear brake pads and brake disc for wear | | <input type="checkbox"/> |
| Visual inspection of brake hoses and connections | | <input type="checkbox"/> |

| | | |
|--|--------------------------|--------------------------|
| Checking brake fluid level, front and rear | | <input type="checkbox"/> |
| 34 00 504 Change brake fluid in entire system | Every 70 operating hours | <input type="checkbox"/> |
| 31 42 501 Fork-leg service (for maintenance) | Every 70 operating hours | <input type="checkbox"/> |
| 33 53 501 Rear spring-strut service (for maintenance) | Every 70 operating hours | <input type="checkbox"/> |
| Checking steering-head bearing | | <input type="checkbox"/> |
| Checking and venting telescopic forks | | <input type="checkbox"/> |
| Checking rear wheel swinging arm and swinging-arm pivot bearings | | <input type="checkbox"/> |
| Checking drive chain, chain guide, sprocket and pinion | | <input type="checkbox"/> |
| Checking chain tension | | <input type="checkbox"/> |
| Checking tires and wheels | | <input type="checkbox"/> |
| Checking freedom of movement of throttle cables and checking for kinks and chafing | | <input type="checkbox"/> |
| Checking battery charge state | | <input type="checkbox"/> |
| Final inspection and check of roadworthiness | | <input type="checkbox"/> |
| Confirming BMW Service in on-board documentation | | <input type="checkbox"/> |