

BMW Motorrad

Maintenance schedule

0186 - F 650 GS Dakar



00 00 122 BMW Service (see Maintenance Schedule) (initially at 10,000 km, then every 20,000 km)

Customer

Registration No.

Odometer reading

Order No.

Date

Mechanic's + Manager's signature

- | | |
|--|--|
| Reading fault-code memories with the BMW Motorrad diagnostic system | <input type="checkbox"/> |
| Changing engine oil (engine and oil tank) and oil filter element | <input type="checkbox"/> |
| Checking coolant level | <input type="checkbox"/> |
| Checking valve clearance | <input type="checkbox"/> |
| Replacing spark plugs | <input checked="" type="checkbox"/> initially at 30,000 km, then every 20,000 km |
| Emptying drain hose from intake air silencer | <input type="checkbox"/> |
| Checking clutch play | <input type="checkbox"/> |
| Checking spoke tension, adjusting if necessary | <input type="checkbox"/> |
| Checking front brake pads for wear | <input type="checkbox"/> |
| Checking front brake disc for wear | <input type="checkbox"/> |
| Checking rear brake pads for wear | <input type="checkbox"/> |
| Checking rear brake disc for wear | <input type="checkbox"/> |
| Checking front brake fluid level | <input type="checkbox"/> |
| Checking brake-fluid level, rear brake | <input type="checkbox"/> |
| Checking chain, chain sprocket and chain pinion | <input type="checkbox"/> |
| Checking chain takeup roller and slider rail | <input type="checkbox"/> |
| Checking chain tension | <input type="checkbox"/> |
| Checking battery acid level | <input type="checkbox"/> |
| Checking steering head bearing play | <input type="checkbox"/> |
| Checking operation of side-stand switch | <input type="checkbox"/> |
| Lubricating side stand | <input type="checkbox"/> |
| Lubricating footbrake lever | <input type="checkbox"/> |
| Checking specified torque of threaded fasteners with torque wrench: engine / main frame, engine / engine | |

carrier and cylinder head / main frame	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: main frame / rear frame, frame bottom section / main frame and engine carrier / main frame	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: footrest plate / main frame and side stand / bottom truss	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: exhaust system	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: spring strut / angled lever / frame / reaction link	<input type="checkbox"/>
Checking tyre pressures and tread depth	<input type="checkbox"/>
Checking lights and signalling equipment	<input type="checkbox"/>
Final inspection and function check	<input type="checkbox"/>
Confirming BMW Service in on-board documentation	<input type="checkbox"/>

not as per the normal schedule

BMW Motorrad, UX-VA-4
06.06.06

BMW recommends 