

BMW Motorrad

Maintenance schedule

0227 - F 800 R, K73 02



Customer

Registration No.

Odometer reading

Order No.

Date

Mechanic's + Manager's signature

00 00 111 BMW Service

- | | | |
|-----------------------------------------------------------------------------------|------------------------------------------------|--------------------------|
| Reading fault memory with BMW Motorrad diagnostic system | | <input type="checkbox"/> |
| 11 00 611 Oil change, engine, with filter | Annually or every 10,000 km | <input type="checkbox"/> |
| 11 34 502 Checking valve clearance (for maintenance) | Every 20,000 km | <input type="checkbox"/> |
| 12 12 509 Replace all spark plugs (as part of maintenance) | Every 40,000 km | <input type="checkbox"/> |
| 13 72 505 Replace air filter cartridge (for maintenance) | Every 20,000 km | <input type="checkbox"/> |
| Checking coolant level | | <input type="checkbox"/> |
| Checking/adjusting clutch play | | <input type="checkbox"/> |
| Checking freedom of movement of throttle cable and checking for kinks and chafing | | <input type="checkbox"/> |
| Checking front brake pads and brake discs for wear | | <input type="checkbox"/> |
| Checking rear brake pads and brake disc for wear | | <input type="checkbox"/> |
| Visual inspection of the brake pipes, brake hoses and connections | | <input type="checkbox"/> |
| Check tire pressures and tread depth | | <input type="checkbox"/> |
| Checking and lubricating chain drive | | <input type="checkbox"/> |
| 34 00 504 Change brake fluid in entire system | Initially after one year, then every two years | <input type="checkbox"/> |
| Checking steering-head bearing | | <input type="checkbox"/> |
| Checking ease of movement of side stand | | <input type="checkbox"/> |
| Checking lights and signaling equipment | | <input type="checkbox"/> |
| Function test, engine start suppression | | <input type="checkbox"/> |
| Final inspection and check of roadworthiness | | <input type="checkbox"/> |
| Reading fault memory with BMW Motorrad diagnostic system | | <input type="checkbox"/> |
| Setting service-due date and service countdown distance | | <input type="checkbox"/> |
| Checking battery charge state | | <input type="checkbox"/> |
| Confirming BMW Service in on-board documentation | | <input type="checkbox"/> |