

# BMW Motorrad

## Maintenance schedule

0146 - G 650 GS Sertão, R13 40



|                      |                      |                                  |
|----------------------|----------------------|----------------------------------|
| <input type="text"/> | <input type="text"/> | <input type="text"/>             |
| Customer             | Registration No.     | Odometer reading                 |
| <input type="text"/> | <input type="text"/> | <input type="text"/>             |
| Order No.            | Date                 | Mechanic's + Manager's signature |

### 00 00 111 BMW Service

|   |  |                          |
|---|--|--------------------------|
| Performing vehicle test with <b>BMW Motorrad</b> diagnostic system                |  | <input type="checkbox"/> |
| 11 00 611 Oil change, engine, with filter   | Annually or every 10,000 km                    | <input type="checkbox"/> |
| 11 34 502 Checking valve clearance (for maintenance)                              | Every 10,000 km                                | <input type="checkbox"/> |
| 12 12 509 Replace all spark plugs (as part of maintenance)                        | Every 20,000 km                                | <input type="checkbox"/> |
| 13 72 505 Replace air filter cartridge (for maintenance)                          | Every 20,000 km                                | <input type="checkbox"/> |
| Checking coolant level  |  | <input type="checkbox"/> |
| Emptying drain hose from intake air silencer                                      |  | <input type="checkbox"/> |
| Checking battery acid level   |  | <input type="checkbox"/> |
| Checking/adjusting clutch play  |  | <input type="checkbox"/> |
| Checking freedom of movement of throttle cable and checking for kinks and chafing |  | <input type="checkbox"/> |
| Checking spoke tension, adjusting if necessary                                    |  | <input type="checkbox"/> |
| Checking tire pressures and tread depth   |  | <input type="checkbox"/> |
| Checking front brake pads and brake discs for wear                                |  | <input type="checkbox"/> |
| Checking rear brake pads and brake disc for wear                                  |  | <input type="checkbox"/> |
| Visually inspect the brake pipes, brake hoses and connections                     |  | <input type="checkbox"/> |
| 34 00 504 Change brake fluid in entire system                                     | Initially after one year, then every two years | <input type="checkbox"/> |
| 33 54 510 Checking threaded fasteners of reaction links (for maintenance)         | Once after one year or once only at 10,000 km  | <input type="checkbox"/> |
| Checking and lubricating chain drive  |  | <input type="checkbox"/> |

- 
- Checking steering-head bearing

---

  - Checking ease of movement of side stand

---

  - Check the lights and signaling equipment

---

  - Function test, engine start suppression

---

  - Final inspection and check of roadworthiness

---

  - Performing vehicle test with **BMW Motorrad** diagnostic system

---

  - Checking battery charge state

---

  - Confirming BMW Service in on-board documentation

---