

# BMW Motorrad

## Maintenance schedule

### 0539 - K 1300 GT, K44 31



<input type="text"/>	<input type="text"/>	<input type="text"/>
Customer	Registration No.	Odometer reading
<input type="text"/>	<input type="text"/>	<input type="text"/>
Order No.	Date	Mechanic's + Manager's signature

#### 00 00 111 BMW Service

- |                                                                 |                                                |                          |
|-----------------------------------------------------------------|------------------------------------------------|--------------------------|
| Reading fault memory with <b>BMW Motorrad</b> diagnostic system |                                                | <input type="checkbox"/> |
| 11 00 609 Oil change in engine with filter (for maintenance)    | Annually or every 10,000 km                    | <input type="checkbox"/> |
| 13 72 505 Replace air filter cartridge (for maintenance)        | Every 20,000 km                                | <input type="checkbox"/> |
| 33 00 501 Oil change, rear wheel drive                          | Every two years or every 20,000 km             | <input type="checkbox"/> |
| Visually inspecting brake pipes, brake hoses and connections    |                                                | <input type="checkbox"/> |
| Checking front brake pads and brake discs for wear              |                                                | <input type="checkbox"/> |
| 34 00 548 Changing brake fluid, front brakes                    | Initially after one year, then every two years | <input type="checkbox"/> |
| Checking rear brake pads and brake disc for wear                |                                                | <input type="checkbox"/> |
| 34 00 549 Changing brake fluid, rear brakes                     | Initially after one year, then every two years | <input type="checkbox"/> |
| Checking clutch system                                          |                                                | <input type="checkbox"/> |
| Checking play of throttle cable                                 |                                                | <input type="checkbox"/> |
| Checking coolant level                                          |                                                | <input type="checkbox"/> |
| Checking tire pressures and tread depth                         |                                                | <input type="checkbox"/> |
| Checking ease of movement of side stand                         |                                                | <input type="checkbox"/> |
| Checking ease of movement of center stand                       |                                                | <input type="checkbox"/> |
| Checking lights and signaling equipment                         |                                                | <input type="checkbox"/> |
| Function test, engine start suppression                         |                                                | <input type="checkbox"/> |
| Final inspection and check of roadworthiness                    |                                                | <input type="checkbox"/> |
| Reading fault memory with <b>BMW Motorrad</b> diagnostic system |                                                | <input type="checkbox"/> |
| Setting service-due date and service countdown distance         |                                                | <input type="checkbox"/> |
| Check the battery charge state                                  |                                                | <input type="checkbox"/> |
| Confirming BMW Service in on-board documentation                |                                                | <input type="checkbox"/> |