

BMW Motorrad

Maintenance schedule

0612 - K 1600 GTL, K48



Customer

Registration No.

Odometer reading

Order No.

Date

Mechanic's + Manager's signature

00 00 111 BMW Service

- | | | |
|--|--|--------------------------|
| Performing vehicle test with BMW Motorrad diagnostic system | | <input type="checkbox"/> |
| 11 00 609 Oil change in engine with filter (for maintenance) | Annually or every 10,000 km | <input type="checkbox"/> |
| 33 74 500 Oil change in rear bevel gears | Every two years or every 20,000 km | <input type="checkbox"/> |
| Draining oil condensate hose | | <input type="checkbox"/> |
| Visually inspecting brake pipes, brake hoses and connections | | <input type="checkbox"/> |
| Checking front brake pads and brake discs for wear | | <input type="checkbox"/> |
| 34 00 548 Changing brake fluid, front brakes | Initially after one year, then every two years | <input type="checkbox"/> |
| Checking rear brake pads and brake disc for wear | | <input type="checkbox"/> |
| 34 00 549 Changing brake fluid, rear brakes | Initially after one year, then every two years | <input type="checkbox"/> |
| Checking clutch system | | <input type="checkbox"/> |
| Checking coolant level | | <input type="checkbox"/> |
| <u>Checking tire pressures and tread depth</u> | | <input type="checkbox"/> |
| Checking ease of movement of side stand | | <input type="checkbox"/> |
| Checking ease of movement of center stand | | <input type="checkbox"/> |
| Checking lights and signaling equipment | | <input type="checkbox"/> |
| Function test, engine start suppression | | <input type="checkbox"/> |
| Final inspection and check of roadworthiness | | <input type="checkbox"/> |
| Performing vehicle test with BMW Motorrad diagnostic system | | <input type="checkbox"/> |
| Setting service-due date and service countdown distance | | <input type="checkbox"/> |
| Checking battery charge state | | <input type="checkbox"/> |
| Confirming BMW Service in on-board documentation | | <input type="checkbox"/> |