

# BMW Motorrad

## Maintenance schedule

### 0470 - R 1200 GS Adventure, K25 32



|                      |                      |                      |
|----------------------|----------------------|----------------------|
| <input type="text"/> | <input type="text"/> | <input type="text"/> |
|----------------------|----------------------|----------------------|

Customer

Registration No.

Odometer reading

|                      |                      |                      |
|----------------------|----------------------|----------------------|
| <input type="text"/> | <input type="text"/> | <input type="text"/> |
|----------------------|----------------------|----------------------|

Order No.

Date

Mechanic's & Manager's signature

#### 00 00 111 BMW Service

|  |   |                          |
|--|---|--------------------------|
| Reading fault memory with <b>BMW Motorrad</b> diagnostic system                  |   | <input type="checkbox"/> |
| 11 00 611 Oil change, engine, with filter  | Annually or every 10,000 km                                       | <input type="checkbox"/> |
| 33 00 501 Oil change, rear wheel drive   | Every two years or every 20,000 km                                | <input type="checkbox"/> |
| 11 34 502 Checking valve clearance (for maintenance)                             | Every 10,000 km   | <input type="checkbox"/> |
| 23 00 510 Gearbox-oil change (maintenance)                                       | Initially after one year, then every two years or every 40,000 km | <input type="checkbox"/> |
| 12 12 509 Replace all spark plugs (as part of maintenance)                       | Every 20,000 km   | <input type="checkbox"/> |
| 13 72 505 Replace air filter cartridge (for maintenance)                         | Every 20,000 km   | <input type="checkbox"/> |
| 12 31 657 Replace belt for generator (as part of maintenance)                    | Every six years or every 40,000 km                                | <input type="checkbox"/> |
| Visual inspection of hydraulic clutch system                                     |   | <input type="checkbox"/> |
| Visually inspecting brake pipes, brake hoses and connections                     |   | <input type="checkbox"/> |
| Checking front brake pads and brake discs for wear                               |   | <input type="checkbox"/> |
| 34 00 548 Changing brake fluid, front brakes                                     | Initially after one year, then every two years                    | <input type="checkbox"/> |
| Checking rear brake pads and brake disc for wear                                 |   | <input type="checkbox"/> |
| 34 00 549 Changing brake fluid, rear brakes                                      | Initially after one year, then every two years                    | <input type="checkbox"/> |
| Checking freedom of movement of Bowden cables and checking for kinks and chafing |   | <input type="checkbox"/> |
| Checking tyre tread depth and tire pressure                                      |   | <input type="checkbox"/> |
| Checking ease of movement of side stand  |   | <input type="checkbox"/> |
| Checking ease of movement of center stand  |   | <input type="checkbox"/> |
| Checking spoke tension, adjusting if necessary                                   |   | <input type="checkbox"/> |
| Checking lights and signaling equipment  |   | <input type="checkbox"/> |
| Function test, engine start suppression  |   | <input type="checkbox"/> |
| 13 60 502 Correcting engine synchronization (for maintenance)                    | Every 10,000 km   | <input type="checkbox"/> |
| Final inspection and check of roadworthiness                                     |   | <input type="checkbox"/> |
| Reading fault memory with <b>BMW Motorrad</b> diagnostic system                  |   | <input type="checkbox"/> |
| Setting service-due date and service countdown distance                          |   | <input type="checkbox"/> |
| Checking battery charge state  |   | <input type="checkbox"/> |

