

# BMW Motorrad

## Maintenance schedule

### 0430 - R 1200 RT, K26 11



Customer

Registration No.

Odometer reading

Order No.

Date

Mechanic's & Manager's signature

#### 00 00 111 BMW Service

Reading fault memory with <b>BMW Motorrad</b> diagnostic system		<input type="checkbox"/>
11 00 611 Oil change, engine, with filter	Annually or every 10,000 km	<input type="checkbox"/>
33 00 501 Oil change, rear wheel drive	Every two years or every 20,000 km	<input type="checkbox"/>
11 34 502 Checking valve clearance (for maintenance)	Every 10,000 km	<input type="checkbox"/>
23 00 510 Gearbox-oil change (maintenance)	Initially after one year, then every two years or every 40,000 km	<input type="checkbox"/>
12 12 509 Replace all spark plugs (as part of maintenance)	Every 20,000 km	<input type="checkbox"/>
13 72 505 Replace air filter cartridge (for maintenance)	Every 20,000 km	<input type="checkbox"/>
12 31 657 Replace belt for generator (as part of maintenance)	Every six years or every 40,000 km	<input type="checkbox"/>
Visual inspection of hydraulic clutch system		<input type="checkbox"/>
Visual inspection of brake pipes, brake hoses and connections		<input type="checkbox"/>
Checking front brake pads and brake discs for wear		<input type="checkbox"/>
34 00 548 Changing brake fluid, front brakes	Initially after one year, then every two years	<input type="checkbox"/>
Checking rear brake pads and brake disc for wear		<input type="checkbox"/>
34 00 549 Changing brake fluid, rear brakes	Initially after one year, then every two years	<input type="checkbox"/>
Checking freedom of movement of Bowden cables and checking for kinks and chafing		<input type="checkbox"/>
Checking tire tread depth and tire pressure		<input type="checkbox"/>
Checking ease of movement of side stand		<input type="checkbox"/>
Checking ease of movement of center stand		<input type="checkbox"/>
Checking lights and signaling equipment		<input type="checkbox"/>
Function test, engine start suppression		<input type="checkbox"/>
13 60 502 Correcting engine synchronization (for maintenance)	Every 10,000 km	<input type="checkbox"/>
Final inspection and check of roadworthiness		<input type="checkbox"/>
Reading fault memory with <b>BMW Motorrad</b> diagnostic system		<input type="checkbox"/>
Setting service-due date and service countdown distance		<input type="checkbox"/>
Checking battery charge state		<input type="checkbox"/>
Confirming BMW Service in on-board documentation		<input type="checkbox"/>

