

# BMW Motorrad

## Maintenance schedule

### 0477 - R 850 RT



00 00 128 BMW Inspection (see Maintenance Schedule) (every 20,000 km)

_____	_____	_____	<b>Equipment trim-level variant:</b> 0369 - Official-user difference
Customer	Registration No.	Odometer reading	
_____	_____	_____	
Order No.	Date	Mechanic's + Manager's signature	

Reading fault-code memories with the BMW Motorrad diagnostic system	<input type="checkbox"/>
Performing bleed test with the BMW Motorrad diagnostic system	<input type="checkbox"/>
Changing engine oil with engine at operating temperature, replacing oil filter	<input type="checkbox"/>
Changing oil in gearbox, warmed to normal operating temperature	<input type="checkbox"/>
33 00 501 Oil change, rear wheel drive *)	<input type="checkbox"/> every two years or every 40,000 km
16 12 525 Replace the fuel filter (during maintenance) *)	<input type="checkbox"/> every 40,000 km
Checking battery acid level	<input type="checkbox"/>
Checking acid level of second battery	<input type="checkbox"/>
Cleaning and greasing battery terminals	<input type="checkbox"/>
Replacing intake air filter	<input type="checkbox"/>
Checking front brake fluid level	<input type="checkbox"/>
Checking brake-fluid level, rear brake	<input type="checkbox"/>
Visual inspection of the brake pipes, brake hoses and connections	<input type="checkbox"/>
Checking front brake pads for wear	<input type="checkbox"/>
Checking front brake discs for wear	<input type="checkbox"/>
Checking rear brake pads for wear	<input type="checkbox"/>
Checking rear brake discs for wear	<input type="checkbox"/>
Checking clutch fluid level	<input type="checkbox"/>
Checking rear wheel bearing play by tilting wheel	<input type="checkbox"/>
Checking swinging-arm pivot mount	<input type="checkbox"/>
Checking operation of side-stand switch	<input type="checkbox"/>
Greasing side stand pivot	<input type="checkbox"/>
12 31 657 Repleace belt for generator (as part of maintenance) *)	<input type="checkbox"/> every 40,000 km

Replacing spark plugs	<input type="checkbox"/>
Adjusting valve clearance	<input type="checkbox"/>
Checking freedom of movement of throttle cable and checking for kinks and chafing	<input type="checkbox"/>
Checking/adjusting synchronisation	<input type="checkbox"/>
Checking tyre pressures and tread depth	<input type="checkbox"/>
Checking lights and signalling equipment	<input type="checkbox"/>
Test ride as final inspection and function check	<input type="checkbox"/>
Confirming BMW Service in on-board documentation	<input type="checkbox"/>

\*) Billed as a separate item

not as per the normal schedule

BMW Motorrad, UX-VA-4  
18.05.06

BMW recommends 