

BMW Motorrad

Maintenance schedule

0187 - F 650 CS



00 00 128 BMW Inspection (see Maintenance Schedule) (every 20,000 km)

_____	_____	_____	Equipment trim-level variant: 0524 - Anti-lock braking system (ABS)
Customer	Registration No.	Odometer reading	
_____	_____	_____	
Order No.	Date	Mechanic's + Manager's signature	

Reading fault-code memories with the BMW Motorrad diagnostic system	<input type="checkbox"/>
Changing engine oil (engine and oil tank) and oil filter element	<input type="checkbox"/>
Checking coolant level	<input type="checkbox"/>
Greasing rubber grommets for cover insert	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>
Draining intake air silencer	<input type="checkbox"/>
Replacing air filter element	<input type="checkbox"/>
16 12 525 Replace the fuel filter (during maintenance) *)	<input checked="" type="checkbox"/> every 40,000 km
Checking battery acid level	<input type="checkbox"/>
Checking clutch play	<input type="checkbox"/>
Checking front brake pads for wear	<input type="checkbox"/>
Checking front brake disc for wear	<input type="checkbox"/>
Checking rear brake pads for wear	<input type="checkbox"/>
Checking rear brake disc for wear	<input type="checkbox"/>
Checking front brake fluid level	<input type="checkbox"/>
Checking brake-fluid level, rear brake	<input type="checkbox"/>
Testing brake system and checking for leaks	<input type="checkbox"/>
32 72 510 Installing repair kit, piston for handbrake fitting (without bleeding) *)	<input checked="" type="checkbox"/> every 40,000 km
34 31 536 Installing piston repair kit in footbrake cylinder (without bleeding) *)	<input checked="" type="checkbox"/> every 40,000 km
27 72 550 Replacing toothed belt with judder damper (for maintenance) *)	<input checked="" type="checkbox"/> every 40,000 km
Checking toothed belt	<input type="checkbox"/>
Checking belt pulley and belt pinion	<input type="checkbox"/>

Checking belt tension	<input type="checkbox"/>
Checking steering head bearing play	<input type="checkbox"/>
Checking operation of side-stand switch	<input type="checkbox"/>
Lubricating side stand	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: engine / engine carrier / frame and cylinder head / main frame	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: main frame and rear frame	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: eccentric clamp	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: exhaust system	<input type="checkbox"/>
Checking tyre pressures and tread depth	<input type="checkbox"/>
Checking lights and signalling equipment	<input type="checkbox"/>
Final inspection and function check	<input type="checkbox"/>
Confirming BMW Service in on-board documentation	<input type="checkbox"/>

*) Billed as a separate item

not as per the normal schedule

BMW Motorrad, UX-VA-4
06.06.06

BMW recommends 