

# BMW Motorrad

## Maintenance schedule

### 0185 - F 650 GS



00 00 128 BMW Inspection (see Maintenance Schedule) (every 20,000 km)

_____	_____	_____
Customer	Registration No.	Odometer reading
_____	_____	_____
Order No.	Date	Mechanic's + Manager's signature

**Equipment trim-level variant:**  
0524 - Anti-lock braking system (ABS)

Reading fault-code memories with the BMW Motorrad diagnostic system	<input type="checkbox"/>
Changing engine oil (engine and oil tank) and oil filter element	<input type="checkbox"/>
Checking coolant level	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>
Emptying drain hose from intake air silencer	<input type="checkbox"/>
Replacing air filter element	<input type="checkbox"/>
16 12 525 Replace the fuel filter (during maintenance) *)	<input checked="" type="checkbox"/> every 40,000 km
Checking clutch play	<input type="checkbox"/>
Checking spoke tension, adjusting if necessary	<input type="checkbox"/>
Checking front brake pads for wear	<input type="checkbox"/>
Checking front brake disc for wear	<input type="checkbox"/>
Checking rear brake pads for wear	<input type="checkbox"/>
Checking rear brake disc for wear	<input type="checkbox"/>
Checking front brake fluid level	<input type="checkbox"/>
Checking brake-fluid level, rear brake	<input type="checkbox"/>
Testing brake system and checking for leaks	<input type="checkbox"/>
32 72 510 Installing repair kit, piston for handbrake fitting (without bleeding) *)	<input checked="" type="checkbox"/> every 40,000 km
34 31 536 Installing piston repair kit in footbrake cylinder (without bleeding) *)	<input checked="" type="checkbox"/> every 40,000 km
Checking chain, chain sprocket and chain pinion	<input type="checkbox"/>
Checking chain takeup roller and slider rail	<input type="checkbox"/>
Checking chain tension	<input type="checkbox"/>
Checking battery acid level	<input type="checkbox"/>

Checking steering head bearing play	<input type="checkbox"/>
Checking operation of side-stand switch	<input type="checkbox"/>
Lubricating side stand	<input type="checkbox"/>
Lubricating centre stand	<input type="checkbox"/>
Lubricating footbrake lever	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: engine / main frame, engine / engine carrier and cylinder head / main frame	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: main frame / rear frame, frame bottom section / main frame and engine carrier / main frame	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: footrest plate / main frame and centre stand / main frame	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: exhaust system	<input type="checkbox"/>
Checking tyre pressures and tread depth	<input type="checkbox"/>
Checking lights and signalling equipment	<input type="checkbox"/>
Final inspection and function check	<input type="checkbox"/>
Confirming BMW Service in on-board documentation	<input type="checkbox"/>

\*) Billed as a separate item

not as per the normal schedule

BMW Motorrad, UX-VA-4  
06.06.06

BMW recommends 