

BMW Motorrad

Maintenance schedule

0244 - F 800 ST



00 00 131 BMW Inspection with Annual Inspection (see Maintenance Schedule) (annually, every 20,000 km)

Customer

Registration No.

Odometer reading

Equipment trim-level variant:

0636 - Centre stand

Order No.

Date

Mechanic's + Manager's signature

Reading fault memory with (BMW Motorrad) diagnostic system	<input type="checkbox"/>
Engine-oil change, with filter	<input type="checkbox"/>
Checking coolant level	<input type="checkbox"/>
17 00 505 Change coolant in system (maintenance) *)	every four years <input checked="" type="checkbox"/>
Reading out countdown distance to next valve-clearance check and replacement of spark plugs	<input type="checkbox"/>
Replacing air filter element	<input type="checkbox"/>
Checking/adjusting clutch play	<input type="checkbox"/>
Visual inspection of the brake pipes, brake hoses and connections	<input type="checkbox"/>
Checking front brake discs for wear	<input type="checkbox"/>
Checking front brake pads for wear	<input type="checkbox"/>
Check the brake-fluid level, front brakes	<input type="checkbox"/>
Check the rear brake disc for wear	<input type="checkbox"/>
Check the rear brake pads for wear	<input type="checkbox"/>
Check the brake-fluid level, rear brakes	<input type="checkbox"/>
34 00 504 Change brake fluid in entire system *)	every two years <input checked="" type="checkbox"/>
27 72 550 Replacing toothed belt with judder damper (for maintenance) *)	every 40,000 km <input checked="" type="checkbox"/>
Checking toothed belt	<input type="checkbox"/>
Checking belt pulley and belt pinion	<input type="checkbox"/>
Checking belt tension	<input type="checkbox"/>
Checking steering head bearing play	<input type="checkbox"/>
Checking ease of movement of centre stand	<input type="checkbox"/>
Checking ease of movement of side stand	<input type="checkbox"/>

Checking tyre pressures and tread depth	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: main frame	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: front footrest plates	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: exhaust manifold	<input type="checkbox"/>
Checking specified torque with torque wrench: eccentric clamp	<input type="checkbox"/>
Checking lights and signalling equipment	<input type="checkbox"/>
Function test, engine start suppression	<input type="checkbox"/>
Test ride as final inspection and function check	<input type="checkbox"/>
Reading fault memory with (BMW Motorrad) diagnostic system	<input type="checkbox"/>
Checking battery charge state	<input type="checkbox"/>
Confirming BMW Service in on-board documentation	<input type="checkbox"/>

*) Billed as a separate item

not as per the normal schedule

BMW Motorrad, UX-VA-4
06.06.06

BMW recommends 