

BMW Motorrad

Maintenance schedule

0145 - G 450 X, K16



<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Customer	Registration No.	Odometer reading	Operating hours
<input type="text"/>	<input type="text"/>	<input type="text"/>	
Order No.	Date	Mechanic's + Manager's signature	

00 00 111 BMW Service

Reading fault memory with BMW Motorrad diagnostic system		<input type="checkbox"/>
11 00 611 Oil change, engine, with filter	Every 10 operating hours	<input type="checkbox"/>
13 72 532 Renewing air cleaner insert	Every 10 operating hours	<input type="checkbox"/>
11 34 502 Checking valve clearance (for maintenance)	Initially after 10 operating hours, then every 20 operating hours	<input type="checkbox"/>
11 00 646 Checking pressure loss with BMW diagnostic unit (spark plug removed)	Initially after 10 operating hours, then every 20 operating hours	<input type="checkbox"/>
Checking spark plug		<input type="checkbox"/>
Checking clean-side chamber of the intake air silencer for leaks		<input type="checkbox"/>
Checking clutch cable and clutch-lever play		<input type="checkbox"/>
Checking fuel system		<input type="checkbox"/>
11 00 647 Engine service	Every 70 operating hours	<input type="checkbox"/>
Checking cylinder head (as part of engine service)		<input type="checkbox"/>
Replacing exhaust valves (as part of engine service)		<input type="checkbox"/>
Replacing spark plug (as part of engine service)		<input type="checkbox"/>
Replacing piston (as part of engine service)		<input type="checkbox"/>
Replacing crankshaft (as part of engine service)		<input type="checkbox"/>
Checking slip coupling in primary drive (as part of engine service)		<input type="checkbox"/>
Checking gearbox (as part of engine service)		<input type="checkbox"/>
Checking and cleaning swinging-arm axle (as part of engine service)		<input type="checkbox"/>
Checking condition of exhaust system		<input type="checkbox"/>
Check the security of the threaded fasteners for frame, side stand and trim panels		<input type="checkbox"/>
Checking cooling system		<input type="checkbox"/>
Checking front brake pads and brake disc for wear		<input type="checkbox"/>
Checking rear brake pads and brake disc for wear		<input type="checkbox"/>
Visual inspection of brake hoses and connections		<input type="checkbox"/>

Checking brake fluid level, front and rear		<input type="checkbox"/>
34 00 504 Change brake fluid in entire system	Every 70 operating hours	<input type="checkbox"/>
31 42 501 Fork-leg service (for maintenance)	Every 70 operating hours	<input type="checkbox"/>
33 53 501 Rear spring-strut service (for maintenance)	Every 70 operating hours	<input type="checkbox"/>
Checking steering-head bearing		<input type="checkbox"/>
Checking and venting telescopic forks		<input type="checkbox"/>
Checking rear wheel swinging arm and swinging-arm pivot bearings		<input type="checkbox"/>
Checking drive chain, chain guide, sprocket and pinion		<input type="checkbox"/>
Checking chain tension		<input type="checkbox"/>
Checking tires and wheels		<input type="checkbox"/>
Checking freedom of movement of throttle cables and checking for kinks and chafing		<input type="checkbox"/>
Checking battery charge state		<input type="checkbox"/>
Final inspection and check of roadworthiness		<input type="checkbox"/>
Confirming BMW Service in on-board documentation		<input type="checkbox"/>