

BMW Motorrad

Maintenance schedule

0178 - G 650 GS, R13 31



<input type="text"/>	<input type="text"/>	<input type="text"/>
Customer	Registration No.	Odometer reading
<input type="text"/>	<input type="text"/>	<input type="text"/>
Order No.	Date	Mechanic's + Manager's signature

00 00 111 BMW Service

Reading fault memory with BMW Motorrad diagnostic system		<input type="checkbox"/>
11 00 611 Oil change, engine, with filter	Annually or every 10,000 km	<input type="checkbox"/>
11 34 502 Checking valve clearance (for maintenance)	every 10,000 km	<input type="checkbox"/>
Checking coolant level		<input type="checkbox"/>
Emptying drain hose from intake air silencer		<input type="checkbox"/>
Checking battery acid level		<input type="checkbox"/>
Checking/adjusting clutch play		<input type="checkbox"/>
Checking freedom of movement of throttle cable and checking for kinks and chafing		<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: engine / main frame, engine / engine carrier and cylinder head / main frame		<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: main frame / rear frame, frame bottom truss / main frame and engine carrier / main frame		<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: exhaust system		<input type="checkbox"/>
Checking spoke tension, adjusting if necessary		<input type="checkbox"/>
Checking tyre pressures and tread depth		<input type="checkbox"/>
34 00 548 Changing brake fluid, front brakes	initially after one year, then every two years	<input type="checkbox"/>
34 00 549 Changing brake fluid, rear brakes	Annually	<input type="checkbox"/>
Checking front brake pads for wear		<input type="checkbox"/>

- | | |
|---|--------------------------|
| Checking front brake disc for wear | <input type="checkbox"/> |
| Checking rear brake pads for wear | <input type="checkbox"/> |
| Checking rear brake disc for wear | <input type="checkbox"/> |
| Visually inspecting brake pipes, brake hoses and connections | <input type="checkbox"/> |
| Lubricating footbrake lever | <input type="checkbox"/> |
| Checking and lubricating chain drive | <input type="checkbox"/> |
| Checking chain takeup roller and slider rail | <input type="checkbox"/> |
| Check the steering-head bearing | <input type="checkbox"/> |
| Checking ease of movement of side stand | <input type="checkbox"/> |
| Checking specified torque of threaded fasteners with torque wrench: footrest plate / main frame and centre stand / main frame | <input type="checkbox"/> |
| Checking lights and signalling equipment | <input type="checkbox"/> |
| Function test, engine start suppression | <input type="checkbox"/> |
| Final inspection and check of roadworthiness | <input type="checkbox"/> |
| Reading fault memory with BMW Motorrad diagnostic system | <input type="checkbox"/> |
| Checking battery charge state | <input type="checkbox"/> |
| Confirming BMW Service in on-board documentation | <input type="checkbox"/> |