

# BMW Motorrad

## Maintenance schedule

### 0165 - G 650 Xchallenge



**00 00 131 BMW Inspection with Annual Inspection (see Maintenance Schedule)** (Annually, every 20,000 km)

Customer

Registration No.

Odometer reading

Order No.

Date

Mechanic's + Manager's signature

Reading fault memory with <b>BMW Motorrad</b> diagnostic system	<input type="checkbox"/>
Changing engine oil (engine and oil tank) and oil filter element	<input type="checkbox"/>
Checking coolant level	<input type="checkbox"/>
Emptying drain hose from intake air silencer	<input type="checkbox"/>
Replacing air filter element	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>
Replacing spark plugs	<input type="checkbox"/>
Checking/adjusting clutch play	<input type="checkbox"/>
Checking freedom of movement of throttle cable and checking for kinks and chafing	<input type="checkbox"/>
Checking spoke tension, adjusting if necessary	<input type="checkbox"/>
Checking front brake disc for wear	<input type="checkbox"/>
Checking front brake pads for wear	<input type="checkbox"/>
Checking brake-fluid level, front brakes	<input type="checkbox"/>
Checking rear brake disc for wear	<input type="checkbox"/>
Checking rear brake pads for wear	<input type="checkbox"/>
Checking brake-fluid level, rear brakes	<input type="checkbox"/>
Visually inspecting brake pipes, brake hoses and connections	<input type="checkbox"/>
34 00 504 Change brake fluid in entire system *)	<input type="checkbox"/>
Checking and lubricating chain drive	<input type="checkbox"/>

Initially after one year, then every two years

- |   |                          |
|---|--------------------------|
| Checking chain take-up rollers and slide rails  | <input type="checkbox"/> |
| Check the steering-head bearing   | <input type="checkbox"/> |
| Checking ease of movement of side stand   | <input type="checkbox"/> |
| Checking tire pressures and tread depth   | <input type="checkbox"/> |
| Checking specified torque of threaded fasteners with torque wrench: cylinder head to frame                | <input type="checkbox"/> |
| Checking specified torque of threaded fasteners with torque wrench: bottom truss to frame                 | <input type="checkbox"/> |
| Checking specified torque of threaded fasteners with torque wrench: swinging-arm bearing stud, left/right | <input type="checkbox"/> |
| Checking lights and signaling equipment   | <input type="checkbox"/> |
| Function test, engine start suppression   | <input type="checkbox"/> |
| Final inspection and check of roadworthiness  | <input type="checkbox"/> |
| Reading fault memory with <b>BMW Motorrad</b> diagnostic system   | <input type="checkbox"/> |
| Checking battery charge state   | <input type="checkbox"/> |
| Confirming BMW Service in on-board documentation  | <input type="checkbox"/> |