

BMW Motorrad

Maintenance schedule

0151 - G 650 XCountry, K15



Customer

Registration No.

Odometer reading

Order No.

Date

Mechanic's & Manager's signature

00 00 111 BMW Service

Reading fault memory with BMW Motorrad diagnostic system		<input type="checkbox"/>
11 00 611 Oil change, engine, with filter	Annually or every 10,000 km	<input type="checkbox"/>
11 34 502 Checking valve clearance (for maintenance)	Every 10,000 km	<input type="checkbox"/>
12 12 509 Replace all spark plugs (as part of maintenance)	Every 20,000 km	<input type="checkbox"/>
13 72 505 Replace air filter cartridge (for maintenance)	Every 20,000 km	<input type="checkbox"/>
Checking coolant level		<input type="checkbox"/>
Checking/adjusting clutch play		<input type="checkbox"/>
Checking freedom of movement of throttle cable and checking for kinks and chafing		<input type="checkbox"/>
Checking spoke tension, adjusting if necessary		<input type="checkbox"/>
Checking front brake disc for wear		<input type="checkbox"/>
Checking front brake pads for wear		<input type="checkbox"/>
Checking rear brake disc for wear		<input type="checkbox"/>
Checking rear brake pads for wear		<input type="checkbox"/>
Visually inspecting brake pipes, brake hoses and connections		<input type="checkbox"/>
Checking brake-fluid level, front brakes		<input type="checkbox"/>
Checking brake-fluid level, rear brakes		<input type="checkbox"/>
Checking and lubricating chain drive		<input type="checkbox"/>
Checking chain take-up rollers and slide rails		<input type="checkbox"/>
Checking ease of movement of side stand		<input type="checkbox"/>
Checking tire pressures and tread depth		<input type="checkbox"/>
31 42 902 Changing fluid in telescopic forks (for maintenance)	Every 30,000 km	<input type="checkbox"/>
Check the steering-head bearing		<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: cylinder head to frame		<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: bottom truss to frame		<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: swinging-arm bearing stud, left/right		<input type="checkbox"/>
Checking lights and signaling equipment		<input type="checkbox"/>

Function test, engine start suppression

Reading fault memory with **BMW Motorrad** diagnostic system

Checking battery charge state

Final inspection and check of roadworthiness

Confirming BMW Service in on-board documentation