

# BMW Motorrad

## Maintenance schedule

### 0151 - G 650 XCountry, K15



Customer

Registration No.

Odometer reading

Order No.

Date

Mechanic's & Manager's signature

#### 00 00 111 BMW Service

|   |  |                          |
|---|--|--------------------------|
| Reading fault memory with <b>BMW Motorrad</b> diagnostic system   |  | <input type="checkbox"/> |
| 11 00 611 Oil change, engine, with filter   | Annually or every 10,000 km                    | <input type="checkbox"/> |
| 11 34 502 Checking valve clearance (for maintenance)  | Every 10,000 km                                | <input type="checkbox"/> |
| 12 12 509 Replace all spark plugs (as part of maintenance)  | Every 20,000 km                                | <input type="checkbox"/> |
| 13 72 505 Replace air filter cartridge (for maintenance)  | Every 20,000 km                                | <input type="checkbox"/> |
| Checking coolant level  |  | <input type="checkbox"/> |
| Checking/adjusting clutch play  |  | <input type="checkbox"/> |
| Checking freedom of movement of throttle cable and checking for kinks and chafing                         |  | <input type="checkbox"/> |
| Checking spoke tension, adjusting if necessary  |  | <input type="checkbox"/> |
| Checking front brake disc for wear  |  | <input type="checkbox"/> |
| Checking front brake pads for wear  |  | <input type="checkbox"/> |
| Checking rear brake disc for wear   |  | <input type="checkbox"/> |
| Checking rear brake pads for wear   |  | <input type="checkbox"/> |
| Visually inspecting brake pipes, brake hoses and connections  |  | <input type="checkbox"/> |
| 34 00 504 Change brake fluid in entire system   | Initially after one year, then every two years | <input type="checkbox"/> |
| Checking and lubricating chain drive  |  | <input type="checkbox"/> |
| Checking chain take-up rollers and slide rails  |  | <input type="checkbox"/> |
| Checking ease of movement of side stand   |  | <input type="checkbox"/> |
| Checking tire pressures and tread depth   |  | <input type="checkbox"/> |
| 31 42 902 Changing fluid in telescopic forks (for maintenance)  | Every 30,000 km                                | <input type="checkbox"/> |
| Check the steering-head bearing   |  | <input type="checkbox"/> |
| Checking specified torque of threaded fasteners with torque wrench: cylinder head to frame                |  | <input type="checkbox"/> |
| Checking specified torque of threaded fasteners with torque wrench: bottom truss to frame                 |  | <input type="checkbox"/> |
| Checking specified torque of threaded fasteners with torque wrench: swinging-arm bearing stud, left/right |  | <input type="checkbox"/> |
| Checking lights and signaling equipment   |  | <input type="checkbox"/> |
| Function test, engine start suppression   |  | <input type="checkbox"/> |

Reading fault memory with **BMW Motorrad** diagnostic system

---

Checking battery charge state

---

Final inspection and check of roadworthiness

---

Confirming BMW Service in on-board documentation

---