

# BMW Motorrad

## Maintenance schedule

### 0554 - K 1200 RS



00 00 131 BMW Inspection with Annual Inspection (see Maintenance Schedule) (annually, every 20,000 km)

_____	_____	_____
Customer	Registration No.	Odometer reading
_____	_____	_____
Order No.	Date	Mechanic's + Manager's signature

Reading fault-code memories with the BMW Motorrad diagnostic system	<input type="checkbox"/>
Checking freedom of movement of throttle cable and checking for kinks and chafing	<input type="checkbox"/>
Changing engine oil with engine at operating temperature, replacing oil filter	<input type="checkbox"/>
Changing oil in gearbox, warmed to normal operating temperature	<input type="checkbox"/>
33 00 501 Oil change, rear wheel drive *)	<input checked="" type="checkbox"/> every two years or every 40,000 km
Checking front brake fluid level	<input type="checkbox"/>
Checking brake-fluid level, rear brake	<input type="checkbox"/>
Checking front brake pads for wear	<input type="checkbox"/>
Checking front brake discs for wear	<input type="checkbox"/>
Checking rear brake pads for wear	<input type="checkbox"/>
Checking rear brake discs for wear	<input type="checkbox"/>
Visual inspection of the brake pipes, brake hoses and connections	<input type="checkbox"/>
Changing brake fluid, front brakes	<input type="checkbox"/>
Changing brake fluid, rear brakes	<input type="checkbox"/>
Checking clutch fluid level	<input type="checkbox"/>
21 00 505 Change the clutch fluid (during maintenance) *)	<input checked="" type="checkbox"/> every four years or every 40,000 km
16 12 525 Replace the fuel filter (during maintenance) *)	<input checked="" type="checkbox"/> every 40,000 km
Checking coolant level and concentration	<input type="checkbox"/>
17 00 505 Change coolant in system (maintenance) *)	<input checked="" type="checkbox"/> every four years
Checking battery acid level	<input type="checkbox"/>
Cleaning and greasing battery terminals	<input type="checkbox"/>
Replacing intake air filter	<input type="checkbox"/>
Checking operation of side-stand switch	<input type="checkbox"/>

Greasing side stand pivot	<input type="checkbox"/>
Checking centre stand	<input type="checkbox"/>
Checking steering damper	<input type="checkbox"/>
Checking rear wheel bearing play by tilting wheel	<input type="checkbox"/>
Checking swinging-arm pivot mount	<input type="checkbox"/>
Checking valve clearance	<input type="checkbox"/>
11 31 705 Additional work: Replace liner on chain tensioning rail, slide rail and thrust block (fuel tank / cylinder head cover removed) *)	every 60,000 km <input type="checkbox"/>
Replacing spark plugs	<input type="checkbox"/>
Checking tyre pressures and tread depth	<input type="checkbox"/>
Checking lights and signalling equipment	<input type="checkbox"/>
Test ride as final inspection and function check	<input type="checkbox"/>
Confirming BMW Service in on-board documentation	<input type="checkbox"/>

\*) Billed as a separate item

not as per the normal schedule

BMW Motorrad, UX-VA-4  
18.05.06

BMW recommends 