

BMW Motorrad

Maintenance schedule

0227 - F 800 R, K73 02



Customer

Registration No.

Odometer reading

Order No.

Date

Mechanic's + Manager's signature

00 00 111 BMW Service

Reading fault memory with BMW Motorrad diagnostic system		<input type="checkbox"/>
11 00 611 Oil change, engine, with filter	Annually or every 10,000 km	<input type="checkbox"/>
11 34 502 Checking valve clearance (for maintenance)	Every 20,000 km	<input type="checkbox"/>
12 12 509 Replace all spark plugs (as part of maintenance)	Every 40,000 km	<input type="checkbox"/>
13 72 505 Replace air filter cartridge (for maintenance)	Every 20,000 km	<input type="checkbox"/>
Checking coolant level		<input type="checkbox"/>
Checking/adjusting clutch play		<input type="checkbox"/>
Checking freedom of movement of throttle cable and checking for kinks and chafing		<input type="checkbox"/>
Checking front brake pads and brake discs for wear		<input type="checkbox"/>
Checking rear brake pads and brake disc for wear		<input type="checkbox"/>
Visual inspection of the brake pipes, brake hoses and connections		<input type="checkbox"/>
Check tire pressures and tread depth		<input type="checkbox"/>
Checking and lubricating chain drive		<input type="checkbox"/>
Checking brake-fluid level, front brakes		<input type="checkbox"/>
Checking brake-fluid level, rear brakes		<input type="checkbox"/>
Checking steering-head bearing		<input type="checkbox"/>
Checking ease of movement of side stand		<input type="checkbox"/>
Checking lights and signaling equipment		<input type="checkbox"/>
Function test, engine start suppression		<input type="checkbox"/>
Final inspection and check of roadworthiness		<input type="checkbox"/>

- | | |
|---|--------------------------|
| Reading fault memory with BMW Motorrad diagnostic system | <input type="checkbox"/> |
| Setting service-due date and service countdown distance | <input type="checkbox"/> |
| Checking battery charge state | <input type="checkbox"/> |
| Confirming BMW Service in on-board documentation | <input type="checkbox"/> |