

BMW Motorrad

Maintenance schedule

0612 - K 1600 GTL, K48



Customer

Registration No.

Odometer reading

Order No.

Date

Mechanic's + Manager's signature

00 00 111 BMW Service

Performing vehicle test with BMW Motorrad diagnostic system		<input type="checkbox"/>
11 00 609 Oil change in engine with filter (for maintenance)	Annually or every 10,000 km	<input type="checkbox"/>
11 34 502 Checking valve clearance (for maintenance)	Every 30,000 km	<input type="checkbox"/>
12 12 509 Replace all spark plugs (as part of maintenance)	Every 30,000 km	<input type="checkbox"/>
13 72 505 Replace air filter cartridge (for maintenance)	Every 20,000 km	<input type="checkbox"/>
33 74 500 Oil change in rear bevel gears	Every two years or every 20,000 km	<input type="checkbox"/>
Draining oil condensate hose		<input type="checkbox"/>
Visually inspecting brake pipes, brake hoses and connections		<input type="checkbox"/>
Checking front brake pads and brake discs for wear		<input type="checkbox"/>
34 00 548 Changing brake fluid, front brakes	Initially after one year, then every two years	<input type="checkbox"/>
Checking rear brake pads and brake disc for wear		<input type="checkbox"/>
34 00 549 Changing brake fluid, rear brakes	Initially after one year, then every two years	<input type="checkbox"/>
Checking clutch system		<input type="checkbox"/>
Checking coolant level		<input type="checkbox"/>
Checking tire pressures and tread depth		<input type="checkbox"/>
Checking ease of movement of side stand		<input type="checkbox"/>
Checking ease of movement of center stand		<input type="checkbox"/>
Checking lights and signaling equipment		<input type="checkbox"/>
Function test, engine start suppression		<input type="checkbox"/>
Final inspection and check of roadworthiness		<input type="checkbox"/>
Performing vehicle test with BMW Motorrad diagnostic system		<input type="checkbox"/>
Setting service-due date and service countdown distance		<input type="checkbox"/>
Checking battery charge state		<input type="checkbox"/>
Confirming BMW Service in on-board documentation		<input type="checkbox"/>